



How do customers use the Perfection V750-M Pro Fluid Mount Accessory?

The Epson Fluid Mount Accessory lets your customers take full advantage of their scanner's capability for high-resolution imaging. When used with a commercial mounting fluid, it holds the film flat to maintain a consistently sharp focus, helps eliminate Newton rings, reduces grain, and reduces the appearance of scratches on silver-based negatives.

Did You Know?

In cases where film holders are not the best solutions for film scanning, the fluid mount accessory offers:






- Scratch removal from film not supported by DIGITAL ICE™ technology such as black and white film
- Easy scanning of film that won't fit into standard film holders
- Reduction of grain and prevention of Newton rings from curved film



Fluid Mount Accessory

How to use the Fluid Mount Accessory

To use the Epson Fluid Mount, you need to obtain these commercially available supplies: scanner mounting fluid and scanner mounting film (clear Mylar® polyester film).

1. Place the fluid mount tray on top of the Epson fluid mount guide.
 
2. Place a drop or two of mounting fluid on the glass tray where you want to mount your film, working quickly so the fluid doesn't evaporate.
 
3. Place your film over the wetted area, using the grid to align your film.
 
4. Apply a small amount of fluid to the top of your film.
5. Place the clear mounting film (cut to fit the fluid mounting tray) on top. Use a lint-free cloth or gloved hands to press outward toward the edges to remove trapped air bubbles.
 
6. After removing the white document mat from the scanner lid, lift the fluid mount tray off the guide and place it on the scanner with the narrow window of the tray toward the back of the scanner.
 
7. Close the scanner cover and scan in Professional Mode, selecting *Film (with Film Holder)* as the Document Type.